Sil5744 韌體更新方法



Sil5744 AP Ver. 5.1.16 所有的檔案


7\桌面\Sil57xx\57xxSteelVine_V5.1.16
5700Package.msi
Windows Installer 封裝
7,641 KB
InstMsiA.Exe
Installer for the Windows Installer
Microsoft Corporation
InstMsiW.Exe
Installer for the Windows Installer
Microsoft Corporation
Setup.Exe
Microsoft (R) Visual Studio Windo...
Microsoft Corporation
Setup.Ini
組態設定值
1 KB
57xx SteelVine
Welcome to the 57xx SteelVine Setup Wizard
Silicon Image
The installer will guide you through the steps required to install Revision 5.1.16 of the 57xx SteelVine storage processor volume management software on your computer.
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.
Cancel
< Back
Next >
1. 執行 Setup.exe
2. 按 Next


檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)
上一頁 搜尋 資料夾
網址(D) H:\57xxSteelVine_V5.1.16
檔案及資料夾工作
將這個檔案重新命名
移動這個檔案
複製這個檔案
將這個檔案發佈到網站
以電子郵件傳送這個檔案
刪除這個檔案
其他位置
TB32 (H:)
我的文件
共用文件
我的電腦
網路上的芳鄰
詳細資料
5700Package.msi
Windows Installer 封裝
7,641 KB
InstMsiA.Exe
Installer for the Windows Installer
Microsoft Corporation
InstMsiW.Exe
Installer for the Windows Installer
Microsoft Corporation
Setup.Exe
Microsoft (R) Visual Studio Windo...
Microsoft Corporation
Setup.Ini
組態設定值
1 KB
57xx SteelVine
License Agreement
Silicon Image
Please take a moment to read the license agreement now. If you accept the terms below, click "I Agree", then "Next". Otherwise click "Cancel".
Silicon Image, Inc.
SOFTWARE LICENSE AGREEMENT
PLEASE READ THE FOLLOWING TERMS AND CONDITIONS CAREFULLY BEFORE DOWNLOADING, INSTALLING OR USING THE SOFTWARE OR ANY ACCOMPANYING DOCUMENTATION (COLLECTIVELY, THE "SOFTWARE").
THE TERMS AND CONDITIONS OF THIS SOFTWARE LICENSE
I Do Not Agree
I Agree
Cancel
< Back
Next >
1. 選擇 I Agree
2. 按 Next


檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)
上一頁 搜尋 資料夾
網址(D) H:\57xxSteelVine_V5.1.16
檔案及資料夾工作
將這個檔案重新命名
移動這個檔案
複製這個檔案
將這個檔案發佈到網站
以電子郵件傳送這個檔案
刪除這個檔案
其他位置
TB32 (H:)
我的文件
共用文件
我的電腦
網路上的芳鄰
詳細資料
5700Package.msi
Windows Installer 封裝
7,641 KB
InstMsiA.Exe
Installer for the Windows Installer
Microsoft Corporation
InstMsiW.Exe
Installer for the Windows Installe
Microsoft Corporation
Setup.Exe
Microsoft (R) Visual Studio Windo...
Microsoft Corporation
Setup.Ini
組態設定值
1 KB
57xx SteelVine
Select Installation Folder
Silicon Image
The installer will install 57xx SteelVine to the following folder.
To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse".
Folder:
C:\Program Files\Silicon Image\57xx SteelVine\
Browse...
Disk Cost...
Install 57xx SteelVine for yourself, or for anyone who uses this computer:
Everyone
Just me
Cancel
< Back
Next >
1. User 選擇 Everyone 或是 Just me
2. 按 Next


檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)
上一頁
搜尋
資料夾
網址(D) H:\57xxSteelVine_V5.1.16
檔案及資料夾工作
將這個檔案重新命名
移動這個檔案
複製這個檔案
將這個檔案發佈到網站
以電子郵件傳送這個檔案
刪除這個檔案
其他位置
TB32 (H:)
我的文件
共用文件
我的電腦
網路上的芳鄰
詳細資料
5700Package.msi
Windows Installer 封裝
7,641 KB
InstMsiA.Exe
Installer for the Windows Installer
Microsoft Corporation
InstMsiW.Exe
Installer for the Windows Installer
Microsoft Corporation
Setup.Exe
Microsoft (R) Visual Studio Windo...
Microsoft Corporation
Setup.Ini
組態設定值
1 KB
57xx SteelVine
Confirm Installation
Silicon Image
The installer is ready to install 57xx SteelVine on your computer.
Click "Next" to start the installation.
Cancel
< Back
Next >
按 Next


57xx SteelVine
Installing 57xx SteelVine
Silicon Image
57xx SteelVine is being installed.
Please wait...
Cancel
< Back
Next >
程式自動安裝



右下角會出現圖示,表示安裝成功


Sil57x4_11516
檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)
上一頁 搜尋 資料夾
網址(D) C:\Documents and Settings\070607\桌面\Sil57x4_11516
移至
檔案及資料夾工作
建立新的資料夾
將這個資料夾發佈到網站
共用這個資料夾
其他位置
桌面
我的文件
我的電腦
網路上的芳鄰
詳細資料
Sil57x4_11516
檔案資料夾
修改日期: 2008年3月4日, 下午 06:52
Sil57x4_11516.bin
BIN 檔案
189 KB
Sil57xx_Release_Notes_90507_fin...
Microsoft Word 文件
149 KB
Sil5744 firmware Ver 1.1516 所有的檔案


57xx SteelVine Manager
File Edit Action Help
Topology
12345678
S/N #12345678
Temperature Fan Speed Drive #0 Drive #1
Box Status N/A N/A Normal Normal
Drive S/N 9QF47BMJ 9QF48SXJ
Exp. S/N 9QF47BMJ 9QF48SXJ
Policy Total Drive #0 Drive #1
Capacity 298.091 GB 298.091 GB
Volume #0 SAFE 298.091 GB 298.091 GB
Silicon Image
Refresh
Quit
自動開啓程式視窗
1. 按兩下圖示
57xx SteelVine Manager
開始
Sil5744update
9.JPG - 小畫家
57xx SteelVine Manager
下午 04:48


57xx SteelVine Manager
File Edit Action Help
選擇 Edit 內的 Specify Firmware
Schedule Drive Verify Ctrl+S
Configure Pop-Ups Ctrl+U
Specify Policy Ctrl+P
Specify Email Notification Ctrl+E
Event Log Ctrl+F
Specify Firmware Ctrl+M
Backup Button Ctrl+T
#12345678
Temperature
Fan Speed
Drive #0
Drive #1
Status
N/A
N/A
Normal
Normal
9QF47BMJ
9QF48SXJ
9QF47BMJ
9QF48SXJ
Policy
Total
Drive #0
Drive #1
Capacity
298.091 GB
298.091 GB
Volume #0
SAFE
298.091 GB
298.091 GB
298.091 GB
Silicon Image
Refresh
Quit

57xx SteelVine Manager
File Edit Action Help
1. 預設密碼爲： admin
Topology
12345678
S/N #12345678
Temperature
Fan Speed
Drive #0
Drive #1
Box Status
N/A
N/A
Normal
Normal
Drive S/N
9QF47BMJ
9QF48SXJ
Exp. S/N
9QF47BMJ
9QF48SXJ
57xx SteelVine Manager Password
To change the firmware requires a password.
Please input your password now.
*****
Cancel
OK
2. 按 Next
Refresh
Quit

57xx SteelVine Manager
57xx SteelVine Manager Firmware
57xx SteelVine Manager ID
IC Revision #
Firmware
Copyright
localhost
57xx SteelVine Manager #12345678 Altair2
1.1516
Copyright 2007, Silicon Image, Inc.
1. 出現 Firmware 更新視窗
2. 按下 Browse
Update firmware image for Sil5744 or Sil5734 from file:
Browse...
Install Firmware
Close Window
Topology
Quit


57xx SteelVine Manager
57xx SteelVine Manager Firmware
Select a Firmware File
查詢(I):
57xx SteelVine
icons
Sil Config
Translations
我最近的文件
桌面
我的文件
我的電腦
網路上的芳鄰
選擇要更新的 Firmware 所在位置
檔案名稱爲：Sil57x4_11516.bin
檔名(N):
檔案類型(T):
Firmware files (*.bin)
開啓(O)
取消
Update firmware image for Sil5744 or Sil5734 from file:
Browse...
Install Firmware
Close Window
Topology
Quit


57xx SteelVine Manager
57xx SteelVine Manager Firmware
Select a Firmware File
查詢(I):
Sil5744update
Sil57x4_11516.bin
我最近的文件
桌面
我的文件
我的電腦
網路上的芳鄰
1. 檔案名稱爲：Sil57x4_11516.bin
2. 開啓
檔名(N):
Sil57x4_11516.bin
開啓(O)
檔案類型(T):
Firmware files (*.bin)
取消
Update firmware image for Sil5744 or Sil5734 from file:
Browse...
Install Firmware
Close Window
Topology
Quit


57xx SteelVine Manager
57xx SteelVine Manager Firmware
57xx SteelVine Manager ID
IC Revision #
Firmware
Copyright
localhost
57xx SteelVine Manager #12345678 Altair2
1.1516
Copyright 2007: Silicon Image, Inc.
按下 Install Firmware
Update firmware image for Sil5744 or Sil5734 from file:
r/桌面/Sil5744update/Sil57x4_11516.bin
Browse...
Install Firmware
Close Window
Topology
Quit


57xx SteelVine Manager
57xx SteelVine Manager Firmware
57xx SteelVine Manager ID
IC Revision #
Firmware
Copyright
localhost
57xx SteelVine Manager #12345678 Altair2
1.1516
Copyright 2007: Silicon Image, Inc.
程式自動更新 Firmware
Update firmware image for Sil5744 or Sil5734 from file:
r/桌面/Sil5744update/Sil57x4_11516.bin
Browse...
Install Firmware
Close Window
50%


57xx SteelVine Manager
57xx SteelVine Manager Firmware
57xx SteelVine Manager ID
IC Revision #
Firmware
Copyright
localhost
57xx SteelVine Manager #12345678 Altair2
1.1516
Copyright 2007: Silicon Image, Inc.
57xx SteelVine Manager
The firmware was successfully downloaded.
For the new firmware to take effect
you must power cycle the SteelVine system.
Shutdown Now
Shutdown Later
更新完成後請選擇 Shutdown Later
Update firmware image for Sil5744 or Sil5734 from file:
r/桌面/Sil5744update/Sil57x4_11516.bin
Browse...
Install Firmware
Close Window


57xx SteelVine Manager
57xx SteelVine Manager Firmware
57xx SteelVine Manager ID
IC Revision #
Firmware
Copyright
localhost
57xx SteelVine Manager #44200027 Altair2
1.1516
Copyright 2007: Silicon Image, Inc.
選擇 Close Window
Update firmware image for Sil5744 or Sil5734 from file:
il5744/Sil57x4_11516/Sil57x4_11516.bin
Browse...
Install Firmware
Close Window
Quit


57xx SteelVine Manager
File Edit Help
Topology
44200027
S/N #44200027
Temperature
Fan Speed
Drive #0
Drive #1
Box Status
N/A
N/A
Unplugged
Unplugged
Drive S/N
Exp. S/N
Policy
Total
Drive #0
Drive #1
Capacity
0 GB
0 GB
Volume #0
BIG Offline
1863.03 GB
931.513 GB
931.513 GB
選擇 Quit
Refresh
Quit

按滑鼠左鍵安全移除裝置

出現此訊息後移除 TB32 上的 USB 線，並關閉 TB32 電源

按滑鼠右鍵，選擇 Exit 結束 Sil57xx AP 程式



重新執行 Sil57xx AP 程式

桌面右下角又會出現 Sil57xx AP 的圖示

* 請更換另一台需要更新 Firmware 的 TB32，接上 USB 及電源線，然後打開電源

重複之前更新 Firmware 的步驟即可繼續更新。